

## Installing Ripley/Ripmo Lower Link Protector

The new lower link protection involves a swingarm rubber tab and a seat tube protective tape.



Clean the seat tube area with Isopropyl alcohol. The seat tube protector is placed starting just above the bottom bracket and follow up the back of the seat tube. The taper on the sticker should follow the shape of the seat tube with the wider part of the sticker starting at the bottom and the narrow part of the sticker ending at the top.



Clean the swingarm with Isopropyl alcohol. The rubber protector adheres to the swingarm in the middle of the uprights. The curve of the protector faces the back of the seat tube and is over the top of the lower link.



Fin.