

MOJO 3

Note on 243 Loctite: Shake the bottle well before applying!

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Cable Port	2 Nm	Grease
Clevis to Swingarm Bolts	8 Nm	Titanium Bolts: Loctite 243 on thread, Ti anti-seize under head of bolt
Lower Links	24 Nm	Loctite 243
Lower Shock to Clevis Bolts	20 Nm	Titanium Bolts: Loctite 243 on thread, Ti anti-seize under head of bolt
Rear Brake Caliper	6 Nm	Loctite 243
Upper Link Bolts	10 Nm	Loctite 243
Upper Shock Mount Bolts	10 Nm	Loctite 243 on thread, grease under head of bolt or mylar washer
Seat Binder	5 Nm	Ti anti-seize
Deraillieur Hanger Bolt	5 Nm	Grease

MOJO HD4

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Cable Port	2 Nm	Grease
Clevis to Swingarm Bolts	15 Nm	Titanium Bolts: Loctite 243 on thread, Ti anti-seize under head of bolt
Lower Links	24 Nm	Loctite 243
Lower Shock to Clevis Bolts	20 Nm	Titanium Bolts: Loctite 243 on thread, Ti anti-seize under head of bolt
Rear Brake Caliper	6 Nm	Loctite 243
Upper Link Bolts	10 Nm	Loctite 243
Upper Shock Mount Bolts	10 Nm	Loctite 243 on thread, grease under head of bolt or mylar washer
Seat Binder	5 Nm	Ti anti-seize
Deraillieur Hanger Bolt	5 Nm	Grease

NOTE: If you have a Mojo 3 or newer HD4 with the black anodized upper shock mount bolt, be sure to use copious amounts of grease under the bolt head if you don't have the mylar washer under the bolt head. Or we'd be happy to send you a washer if you don't have one.

RIPLEY LS

Note on 243 Loctite: Shake the bottle well before applying!

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Clevis to Swingarm Bolts	8 Nm	Grease
Lower Shock to Clevis Bolts	24 Nm	Loctite 243
Eccentric Shaft Bolts	8 Nm	Titanium Bolts: Loctite 243 on thread, Ti anti-seize under head of bolt
Upper and Lower Eccentric Core Bolts	8 Nm	Loctite 243
Upper Shock Mount Bolts	10 Nm	Loctite 243
Seat Binder	5 Nm	Ti anti-seize
Deraillieur Hanger Bolt	5 Nm	Grease

RIPMO

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Lower Link 6mm Preload Bolts	2 Nm	Loctite 243 on thread, grease on flange
Lower Link 5mm pinch bolts	10 Nm	Loctite 243
Swingarm to Clevis pivot bolts	5 Nm	Loctite 243
Lower shock clevis bolt	20 Nm	Ti anti-seize
Upper link bolts	10 Nm	Loctite 243
Forward shock mount bolt	10 Nm	Loctite 243
Seat Binder	5 Nm	Ti anti-seize
Deraillieur Hanger Bolt	5 Nm	Grease

HAKKA MX

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Seat Binder	5 Nm	Ti anti-seize
Deraillieur Hanger Bolt	5 Nm	Grease

BUSHINGS

On all models, apply Slick Honey (grease) to all bushings during reassembly.

HEXLE REAR AXLE

There is not a numerical torque figure for the Hexle. We recommend tightening the 5mm with your multi tool that you carry with you. This way you'll be able to remove it in case of a flat out on a ride.

